



**TOOLS NEEDED:**

- 1/8" Bit
- Torx T20 bit
- 7/16" nut driver
- 1/4" ratchet



## INSTALLATION INSTRUCTIONS



Remove floor covering from trunk and OEM plastic trim.



Using a Torx T20 bolt from cargo hook (set aside will not reuse).



Remove (1) plastic screw clip from upper section nearest tail light.



Pull (2) plastic clips from lower area nearest tail light.



Pull carpet away from frame, disconnect wire harness for trunk light.



From underside of carpet, remove foam pad.



Place Mounting Plate, keeping tabs toward outside of car. Line up the notch around OEM section, using passenger side (P) / driver side (D). Mark (4) hole locations and predrill holes using a 1/8" bit.



Secure Mounting Plate using provided (4) self-tapping screws.



Reconnect wire harness, replace carpet, (1) screw clip, and the lowest (1) plastic clip. Replace floor covering.



## INSTALLATION INSTRUCTIONS



Position Side Mount Tray into proper location.

**NOTE: Allow room for access to battery and spare tire. Line hole on Side Mount Tray to line up with OEM hole location where cargo hook was removed.**



Carefully lower the Side Mount Tray, keeping in proper location. Move the tray aside and predrill through floor covering into Mounting Plate using 1/8" bit.



Secure Side Mount Tray into position using provided self tapping screws. Lift Side Mount Tray into the closed position, to check thumb screw hole. Secure into OEM hole.



Outside of vehicle, attach equipment onto the Equipment Plate. Lower Side Mount Tray and put Equipment Plate into position, onto studs and secure into place using provide flange nuts.

