



GUN RACK - HORIZONTAL MOUNT TO PARTITION WINDOW

GR1-870-H

Installation Instructions

475-0016

PARTS LIST



(1) MOMENTARY SWITCH



(1) LOCK TIMER



(2) 3/4" DELRON SPACERS



(2) 1/4"-20 x 1.5" CARRIAGE BOLTS



(2) 1/4"-20 WHIZ NUTS



(1) ASSEMBLED WEAPON MOUNT



1. Start by removing the (2) Factory 1/4" nuts and carriage bolts using a 7/16" wrench or socket. Remove the ones on the top section in the outer position of window frame on partition.

2. Insert the 1.5" carriage bolts thru now open holes in partition, place delron spacers on bolts, and position weapon mount on these bolts with tabs of weapon mount rail down. Secure to partition with the whiz nuts.



If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 2/25

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.

050-0234-00

