



ABS DOOR PANELS

2011+ DODGE CHARGER

Installation Instructions

475-0231

INCLUDES:

- (1) Driver Side Door Panel
- (1) Passenger Door Panel
- (2) Door Panel Spacer Brackets
- (6) Button Socket Head Cap Screws
- (8) Phillips Truss Head Screws

*****Complete this installation before installing Window Armor*****

1 - Remove OEM Door Panel and unplug electric connectors for the power window and lights (Pic 1 & 2).

2 - Make sure power window switch is connected to the harness. "Bag & Seal" connectors to protect them. Tuck into door frame and secure with plastic tie.

3 - Remove three (3) Hex Head Bolts from the top of the inner OEM door frame (Pic 3). Use OEM bolts to attach Door Panel Spacer Brackets.

4 - Attach Door Panel to Door Panel Spacer Brackets with Button Socket Head Cap Screws (Pic 4).

5 - Drill 7/64" pilot holes through the four (4) holes around the bottom and side edges of the Door Panel. Attach the Phillips Truss Head Screws into the pilot holes (Pic 5).



Pic 1



Pic 2



Pic 3



Pic 4



Pic 5

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 1/25

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.

050-0138-00

