Space Creator Vehicle Partition

475-1057 / 475-1104

Ford F-150 SSV (2015-2020), F-150 Police Responder (2018+), and F-250 (2019+)

Installation Instructions

If you have questions or need further assistance please call
Technical Support: 1.877.455.6886

Before beginning the installation, confirm that you have received all of the parts for your package. Read the instructions completely before starting installation.

475-1057
Space Creator Vehicle Partition
with High Security/High Visibility Window
U.S. Patent No. 8,690,216

TOOLS NEEDED:

- Ratchet
- 7⁄16" Socket
- 10 mm Socket
- T50 Torx Bit Socket

PARTS INCLUDED:

- Hardware Bag with necessary nuts, bolts, etc.

475-1104
Space Creator Vehicle Partition
with Full Window and Safety Wire
U.S. Patent No. 8,690,216

Center HSEP

(2) B Pillar Bracket

Wings Set

Bi-Directional
Recessed Housing

(2) Mounting Foot

Installation Instructions

If you have questions or need further assistance please call
Technical Support: 1.877.455.6886

Begin by removing rear OEM trim cover from outer rail of front seat. Pull trim away from seat rail. Repeat on other side.

Move seats completely forward. Loosen the rear/outer OEM 13mm seat bolt exposed when OEM trim was removed.

Push seat up slightly to slide the Foot Mount Bracket under seat rail, between rail and carpet. Leave bolt loose at this time. Repeat on other side.

Use a small screw driver to pop the lower cover off of the entry assist handle.

Remove 7mm bolt from inside handle. Repeat on other side.

Use provided 5mm hex bolt & spacer to loosely attach B Pillar Bracket, through lower opening in entry assist handle. Repeat for other side.

Install Partition frame into vehicle through PS door and position onto mounting feet.

Lean Partition frame forward and loosely attach B Pillar Brackets to middle hole of frame. Center the partition. Once centered, tighten all hardware at this time.

Loosely attach Center HSEP onto BDRH outside of vehicle using (6) carriage bolts and flange nuts.

Installation Instructions

If you have questions or need further assistance please call
Technical Support: 1.877.455.6886

Place BDRH with Center HSEP into vehicle. Attach BDRH to Partition Frame using provided carriage bolts and flange nuts. Push carriage bolts in from prisoner side of partition.
Tighten all bolts/nuts.

SOLO INSTALL NOTE: Use masking tape over carriage bolts to hold bolt in place while attaching flange nuts from front side of partition.

Install Lower Steel Wing from prisoner side using (3) carriage bolts and flange nuts. Repeat on other side.

Install Upper Poly Wing from officer side using a carriage bolts and flange nuts on the upper and lower hole. Repeat on other side.

Install black caps on all flange nuts.

Jotto Desk® is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.