

# WINDOW ARMOR (BAR STYLE)

CHEVY TAHOE 2021+

475-1718

## Installation Instructions



### INCLUDES:

- (1) Driver Side Window Armor
- (1) Passenger Side Window Armor

1. Place Bar Style Window Armor on the door frame.
2. Curve of Bar Style Window Armor should be away from prisoner area.
3. There are holes around the perimeter of the Bar Style Window Armor that match the top curve of door frame.
4. Use provided hardware (#8 Phillips Screws) to attach Window Armor to Door Frame.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • [www.JottoPublicSafety.com](http://www.JottoPublicSafety.com) • 3/21

Jotto Desk® is a patented product and Registered Trademark of Assembled Products™ Corporation.  
Specifications subject to change without notice.