



GR6-SUV-870-AR-BLM

VERTICAL DUAL WEAPON, REAR SEAT MOUNTED GUN RACK

Installation Instructions

475-0538



Parts Included:

- Hardware Bag With Necessary Nuts, Bolts, Etc.
-
1. Position weapon mount in desired location. We intend for this mount to be secured on the floor of the SUV/Pickup. Use the mounting plate as a template to mark holes. Then follow AVK installation sheet.
 2. Position weapon mount and secure with the socket cap screws and tighten bolts securely.
 3. Install weapon and check for secure fit.
 4. Press on lock head cover to ensure it is locked.

AVK FASTENER INSTALLATION INSTRUCTIONS



AVK Installation video can be viewed at:
<http://jottopublicsafety.gojotto.com/additional-categories/downloads.html>



1. Drill out existing hole to 1/2" or drill new hole per installation instructions.



2. Place 5/16-18 x 1.5" long bolt through the 3/8" flange nut and hand thread bolt into the AVK Fastener.



3. Place into 1/2" drilled hole.



4. Use 9/16" box end wrench to secure the flange nut.



5. Apply pressure on the flange nut, pressing AVK Fastener into hole.
6. Using an air wrench, tighten the 5/16-18 x 1.5" bolt.



7. This will allow the AVK Fastener to secure onto the backside of the metal.
8. Remove 5/16-18 x 1.5" bolt.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 3/25

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.

050-0240-00

