



WWW.JOTTODESK.COM
877.455.6886



INSTALLATION INSTRUCTIONS **(‘09-’14, 28” F150 Floor Plate)** **425-6142**

STEP 1: Check to see that you have all of the parts listed above.

STEP 2: Loosen front and rear inside driver and passenger seat bolts and then remove (2) screws pull tray out taking care and unplug 12V outlet. Remove (2) bolts under seat and pull jump seat out. Tighten seat bolts.

STEP 3: Place F150 Floor Plate onto center hump and secure in place through side of plate using OEM bolts from jump seat removal. Place Extruded Floor Plate on top of F150 Floor plate and secure using 5/16"-18 x 3/4" counter sink bolt.

NOTE: Height adjustment at front of floor plate to level plate.

STEP 4: Slide two provided hex head bolts down each side rail of floor plate, 425-1604. Align the bolts with the holes located at the top of the mounting legs. Using the provided washers and nylock nuts, secure the floor plate to the legs. Make necessary adjustments to the height of floor plate (both the legs and the leveler) and tighten ALL bolts.

STEP 5: Insert hex head bolts into the outside slots on top of the floor plate, two on each side. (These will be used to secure the console to the floor plate)

STEP 6: Position console, 425-2400, on top of the floor plate, with bolts (step 6) inserted through slots located at the bottom of the console.

STEP 7: Slide the console into desired position. Using provided washers and nylock nuts, secure console to the floor plate.

