



# ZEBRA I4CC

## FACEPLATE

### Installation Instructions

425-6543



1



Mount the Brother printer faceplate into the bottom of the Jotto Desk console.

2



Loosen knob to release the printer faceplate from its secure position.

3



Pull up to remove faceplate with printer from console when the paper roll needs changing.



For use with the...

**ZEBRA** ZQ520 4" Printer

SCAN QR CODE FOR VIDEO



## ORDERING INFORMATION

425-6543 7" Faceplate for Zebra ZQ520 4" Printer

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 2/25

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.  
Specifications subject to change without notice.

