


425-6543

7" PRINTER FACEPLATE for ZEBRA 4" PRINTER



For use with the...
 **ZEBRA** ZQ520 4" Printer

ORDERING INFORMATION

425-6543 7" Faceplate for Zebra ZQ520 4" Printer

1



Mount the Zebra printer faceplate into the bottom of the Jotto Desk console.

2



Loosen knob to release the printer faceplate from its secure position.

3



Pull up to remove faceplate with printer from console when the paper roll needs changing.

SCAN QR CODE FOR VIDEO

